


Fundamental and Applied Research of Nano-Particle Measurement

Terunao KAWAI
National Traffic Safety and Environment Lab.
JAPAN



What is nano Particle?




Source: David Kittelson



Why do we need to consider nano PM?

Human body significantly reacts to diesel nano-particles.
Small particles are too dangerous to nervous system.



National Traffic Safety and Environment Laboratory, JAPAN NITSEL

Problems of Nano-PM Measurement

There are many different instruments available for counting particles under steady state and transient conditions. None of them can give very accurate and repeatable results.

↓ *Because*

Nano-particles are very unstable and sensitive to dilution process and ambient condition such as temperature, humidity and residence time.

↓ *Necessity*

To make the nano-particles characteristically stable so that accurate and repeatable measurement will be possible.

National Traffic Safety and Environment Laboratory, JAPAN NITSEL

Fundamental Research

Motivation


Discussion started in the PMP under the auspices of GRPE

↓ PMP Recommendation

Thermal Conditioning of exhaust gas in order to restrain
the fluctuation in nano-particle measurement

↓ Objective of ThC

Vaporizing and eliminating the volatile fractions




Objective

It is a newly developed device
The characteristics of the thermo-conditioned
nano-particles are completely unknown under
different ambient and engine operating conditions.

To investigate


- Effect of thermo-conditioner/evaporator on the nano particles
- Clarify the thermo-physical behavior of the conditioned nano particles
- Testing the stability and repeatability of nano particles measurement
- Clarify the characteristics of nano-particle and **build up the Nano-Particle Model** from thermal behavior.

Thermo-Conditioner




Specifications of ThC

Dimension (mm)	400 x 132 x 448
Flow rate	1 to 5 Liter/min
Heating range	0 to 400 ° C



Experiment System



Engine specification

Engine type	DI Diesel
Injection system	Common rail
Bore X Stroke	114 X 130 mm
Swept volume	7.96 Liter
Emission standard	Japan 1998
Max Power kW/rpm	191/2700
Max Torque Nm/rpm	745/1600


Test Conditions

Idling	550 rpm 0 N-m
Low load	1200 rpm 98 N-m
Medium load	1620 rpm 460 N-m

Results and Discussion

- Effect of Sampling Points
- Effect of Hot Dilution Temperature
- Effect of Thermo-Conditioner


Effect of Sampling Point on Nano-PM



Idling Condition:
Speed: 550 rpm
Torque: 0 N-m

BS: Before Silence
BDT: Before Dilution Tunnel
ADT: After Dilution Tunnel


Effect of Sampling Point on Nano-PM




Low load Condition:
Speed: 1200 rpm
Torque: 98 N-m

BS: Before Silence
BDT: Before Dilution Tunnel
ADT: After Dilution Tunnel

Nano-PM Smaller than 10 nm




Effect of Dilution Temperature on Nano-PM




Sampling point: Before silencer
Idling condition: 550 rpm, 0 N-m

Effect of Thermo-Conditioner on Nano-PM



Nano-Particle Model




Types of Nano-Particles



± 100 nm
Solid particles (soot)
Agglomerate of soot

Accumulation mode particles:

These cannot be vaporized/desorbed significantly by thermal-conditioning.



15~30 nm
Volatile particles

Nuclei-mode particles:

Nucleate due to cold dilution but vaporizes/desorbs under thermo-conditioning even at 100 °C

15~30 nm
Semi-volatile particles

Nucleate due to cold dilution but vaporizes/desorbs slightly or becomes smaller in size under thermo-conditioning at 100~300 °C




≤ 10 nm
Ash/Carbon/Heavy HC



Do not vaporize/desorb or change in size under thermo-conditioning even above 400 °C

Applied Research


Concept of New Measurement Device



Dual-type DMA



Experimental setup



National Traffic Safety and Environment Laboratory, JAPAN NITSEL

Influence of Oxidation Cat.






図9-2 全量希釈トンネル後の排出ナノ粒子の挙動 (酸化触媒有無の影響)

National Traffic Safety and Environment Laboratory, JAPAN NITSEL


Comparative Experiment




Result from Dual-DMA European Small Diesel Vehicle




Result from Dual-DMA Gasoline Direct Injection Vehicle



Concept of Popularized Nano-particle Measurement Device



Popularized Nano-particle Measurement Device



Conclusions

Nuclei-mode particles having the diameter of about 15-30 nm is significantly influenced by the thermal conditioning temperature while the accumulation mode particles having the diameter of about 100 nm remain almost the same.

Thermo-conditioner can vaporize almost all the volatile fraction forms due to cold dilution in the full dilution tunnel. But the effect on combustion-generated nuclei-mode particles (core) is not clear.

A hypothetical model for diesel nano-particles distribution has been developed depending on the characteristics.

We develop a new nano-particle measurement devices based our new knowledge.

Acknowledgement

*This work is supported by the
JRTT*

*This work was done with
Dr. Rahman M. Montajir*